


## USB Installation Guide


1. Place the printer on a flat, secure surface.
2. Make sure the power switch is off.
3. Connect the printer to the computer with the USB cable.
4. Plug the power cord into the power supply connector at the rear of the printer, and then plug the power cord into a properly grounded receptacle. Turn on the printer.




5. Insert the CD-ROM at CD-ROM drive after hardware installed properly. Please click “Windows Driver Setup” to start.




6. Select “Install printer drivers” to next.




7. Select “Install a driver for a Plug and Play printer” to next.




8. Enter the "Printer name" to next.



9. Click "Finish" to install the Windows Driver.



10. Windows has finished installing the software for this device. Click "Close" to exit the wizard.



**ALTAREX** jest wiodącym dostawcą całej gamy urządzeń do systemów informatycznych wykorzystujących automatyczną identyfikację produktów, w oparciu o technikę kodów kreskowych, jak również z zastosowaniem nowych technologii, na przykład RFID.



## **OFERUJEMY :**

- Weryfikatory jakości kodów kreskowych
- Czytniki kodów kreskowych
- Drukarki etykiet termiczne i termotransferowe
- Drukarki etykiet kolorowych
- Terminale przenośne
- Terminale radiowe
- Automatyczne czytniki przemysłowe
- Etykiety samoprzylepne
- Taśmę termotransferową
- Materiały specjalne na zamówienie

ALTAREX Sp.J.  
ul. Majerankowa 12A  
04-889 Warszawa  
tel (22) 632 07 93, 632 61 91  
e-mail: [altarex@altarex.com.pl](mailto:altarex@altarex.com.pl)